

Ruijie RG-AP820-L(V3) Access Point

Hardware Installation and Reference Guide

Copyright

Ruijie Networks©2022

Ruijie Networks reserves all copyrights of this document.

Any reproduction, excerption, backup, modification, transmission, translation or commercial use of this document or any portion of this document, in any form or by any means, without the prior written consent of Ruijie Networks is prohibited.

Trademarks including ,  and  are owned by Ruijie Networks.

All other trademarks or registered trademarks mentioned in this document are owned by their respective owners.

Disclaimer

The products, services or features you purchase are subject to commercial contracts and terms. Some or all of the products, services or features described in this document may not be within the scope of your purchase or use. Unless otherwise agreed in the contract, Ruijie Networks does not make any express or implied statement or guarantee for the content of this document.

Due to product version upgrades or other reasons, the content of this document will be updated from time to time. Ruijie Networks reserves the right to modify the content of the document without any notice or prompt.

This manual is for reference only. Ruijie Networks endeavors to ensure content accuracy and will not shoulder any responsibility for losses and damages caused due to content omissions, inaccuracies or errors.

Preface

Intended Audience

This document is intended for:

- Network engineers
- Technical support and servicing engineers
- Network administrators


Technical Support

- Ruijie Networks Website: <https://www.ruijienetworks.com/>
- Technical Support Website: <https://ruijienetworks.com/support>
- Case Portal: <http://caseportal.ruijienetworks.com>
- Community: <http://community.ruijienetworks.com>
- Technical Support Email: service_rj@ruijienetworks.com
- Skype: [service_rj@ruijienetworks.com](https://www.skype.com/people/service_rj@ruijienetworks.com)


Conventions

1. Signs


The symbols used in this document are described as follows:

 **Danger**


An alert that calls attention to safety operation instructions that if not understood or followed when operating the device can result in physical injury.

 **Warning**


An alert that calls attention to important rules and information that if not understood or followed can result in data loss or equipment damage.

 **Caution**

An alert that calls attention to essential information that if not understood or followed can result in function failure or performance degradation.

 **Note**

An alert that contains additional or supplementary information that if not understood or followed will not lead to serious consequences.

 **Specification**

An alert that contains a description of product or version support.

2. Note

This manual provides the device installation steps, hardware troubleshooting, module technical specifications, and specifications and usage guidelines for cables and connectors. It is intended for the users who have some experience in installing and maintaining network hardware. At the same time, it is assumed that the users are already familiar with the related terms and concepts.

Contents

Preface.....	1
1 Product Overview	1
1.1 Appearance	1
1.2 Package Contents.....	3
1.3 Technical Specifications.....	3
1.3.1 Size and Weight.....	3
1.3.2 RF.....	4
1.3.3 Ports	5
1.3.4 Power Supply.....	5
1.3.5 Environment and Reliability.....	5
1.4 Indicator and Button Description	6
1.5 SFP Modules.....	7
2 Preparing for Installation	9
2.1 Safety Precautions	9
2.1.1 General Safety Precautions.....	9
2.1.2 Handling Safety.....	9
2.1.3 Electric Safety	9

2.1.4 Storage Safety	10
2.2 Installation Environment Requirements	10
2.2.1 Bearing Requirements.....	10
2.2.2 Ventilation Requirements	10
2.2.3 Space Requirement	10
2.2.4 Temperature/Humidity Requirements.....	10
2.2.5 Cleanliness Requirements.....	11
2.2.6 Anti-interference Requirements	12
2.2.7 Lightning Protection Requirements	12
2.2.8 Installation Site Requirements.....	12
2.3 Tools.....	12
3 Installing the Access Point	13
3.1 Installation Flowchart.....	13
3.2 Before You Begin	13
3.3 Precautions.....	14
3.4 Installing the Access Point.....	15
3.4.1 Ceiling Mounting.....	15
3.4.2 Wall Mounting	16

3.5 Securing the Access Point	18
3.6 Installing the SFP Module.....	19
3.7 Removing the Access Point.....	20
3.8 Connecting Cables.....	21
3.9 Bundling Cables	21
3.9.1 Precautions	21
3.9.2 Bundling Steps	21
3.10 Checking after Installation	21
3.10.1 Checking Cable Connection	21
3.10.2 Checking Power Supply	22
4 Verifying Operating Status.....	23
4.1 (Optional) Configuring the Environment.....	23
4.2 Powering up the AP	23
4.2.1 Checking Environment before Power-on.....	23
4.2.2 Checking Environment after Power-on.....	23
5 Monitoring and Maintenance	24
5.1 Monitoring	24
5.1.1 LED.....	24

5.1.2 CLI Commands	24
5.2 Remote Maintenance	24
5.3 Hardware Maintenance.....	24
6 Troubleshooting	25
6.1 Troubleshooting Flowchart	25
6.2 Typical Troubleshooting Cases	25
6.2.1 Ethernet Port Does Not Work After Being Connected to an Ethernet Cable.....	25
6.2.2 Indicator Is Off for a Long Time	25
6.2.3 Indicator Remains Red for a Long Time.....	26
6.2.4 Indicator Remains Green for a Long Time	26
6.2.5 Indicator Fast Blinks in Blue (Fit AP)	26
6.2.6 Indicator Is Not Steady Blue or Does Not Blink in Blue	26
6.2.7 Users Cannot Find Wireless Signals	26
7 Appendix.....	27
7.1 Connectors and Media.....	27
7.2 Mini-GBIC Modules	29
7.3 Cabling Recommendations	30
7.4 Power Supply	33

1 Product Overview

The RG-AP820-L(V3) AP is a dual-radio access point compliant with the IEEE 802.11ax standard. The RG-AP820-L(V3) AP provides a combined data rate of 2.976 Gbps, with up to 574 Mbps in the 2.4 GHz band and 2.402 Gbps in the 5 GHz band. Designed for flexible deployments in the field of education, government, finance and business, the RG-AP820-L(V3) AP offers one combo port.

1.1 Appearance

The RG-AP820-L(V3) provides two radio frequency (RF) connectors, one 10/100/1000 BASE-T Ethernet port, one 2.5G SFP port, one Console port and one DC power plug. The AP supports PoE or DC power supply.

Figure 1-1 Appearance



Figure 1-2 Front Panel



Table 1-1 Front Panel

No.	Item	Description
1	LED	Indicate the operation status of device.

Figure 1-3 Side View




Table 1-2 Side View

No.	Button and Port	Description
1	LED	Indicate the operation status of device.
2	2.5G SFP	2.5G SFP port
3	Reset	Reset button
4	Console	Console port
5	LAN/10GbE	LAN/10GbE port
6	48V PoE	48V PoE port

1	Anti-theft lock hole	Connect to the anti-theft lock.
2	2.5G SFP port	The uplink SFP port for service data transmission.
3	Reset button	Reboot the device or restore the device to factory settings.
4	Console port	Connect to the device that is managed with the serial cable.
5	1000 BASE-T Ethernet port	The uplink adaptive Ethernet port for service data transmission. Support IEEE 802.3af standard PoE power supply.
6	DC power plug	Connect to the DC power adapter to supply power to the AP.

1.2 Package Contents

Table 1-3 Package Contents

Item	Quantity
RG-AP820-L(V3) Access Point	1
Mounting Bracket	1
Wall Anchor	2
Phillips Pan Head Screws M4 x 20	4
Warranty Card	1
Installation Guide	1

1.3 Technical Specifications

1.3.1 Size and Weight

Table 1-4 Size and Weight

Item	Parameter
Main Unit Dimensions (W x D x H)	222 mm x 220 mm x 49 mm (8.74 in. x 8.74 in. x 1.93 in.)
Weight	Main Unit: 1.0 kg (2.20 lbs.) Bracket: 0.2 kg (0.44 lbs.)
Mounting	Ceiling/wall mount capable
Anti-theft Lock	Kensington lock Security screw

Bracket Dimensions (W x D x H)	120 mm×120 mm×8 mm (4.72 in. x 4.72 in. x 0.31 in.)
Mounting Hole Pattern	53 mm (2.09 in.) x 53 mm (2.09 in.)
Mounting Hole Diameter	6.5 mm (0.26 in.)

1.3.2 RF

Table 1-5 RF

Item	Parameter
RF Design	2 RF connectors Radio1: 2.4 GHz, 2×2 MIMO (2 spatial streams) Radio2: 5 GHz, 2×2 MIMO (2 spatial streams) Combined dual-band:4 spatial streams
Operating Frequency	Radio1: 802.11b/g/n/ax, 2.4 GHz-2.483 GHz, HE40 Radio2: 802.11a/n/ac/ax, 5.150 GHz-5.350 GHz, HE80/HE160 802.11a/n/ac, 5.470 GHz-5.725 GHz, 5.725 GHz-5.850 GHz, HE80 (country-specific restrictions apply)
Max. Data Rate	Radio1: 2.4 GHz, 574 Mbps Radio2: 5 GHz, 2.402 Gbps Combined dual-band: 2.976Gbps
Antenna Type	Built-in omnidirectional antenna
Antenna Gain	2.4 GHz: 3 dBi 5 GHz: 3 dBi
Max. Transmit Power	20 dBm (country-specific restrictions apply)
Transmit Power Adjustment	Configurable in increments of 1 dBm
Modulation	OFDM: BPSK@6/9Mbps, QPSK@12/18Mbps, 16-QAM@24Mbps, 64-QAM@48/54Mbps

	DSSS: DBPSK@1Mbps, DQPSK@2Mbps, and CCK@5.5/11Mbps MIMO-OFDM: BPSK, QPSK, 16QAM, 64QAM, 256QAM and 1024QAM OFDMA
Receive Sensitivity	11b: -96dBm(1Mbps), -93dBm(5Mbps), -89dBm(11Mbps) 11a/g: -91dBm(6Mbps), -85dBm(24Mbps), -80dBm(36Mbps), -74dBm(54Mbps) 11n: -90dBm@MCS0, -70dBm@MCS7, -89dBm@MCS8, -68dBm@MCS15 11ac: HT20: -88dBm(MCS0), -63dBm(MCS9) 11ac: HT40: -85dBm(MCS0), -60dBm(MCS9) 11ac: HT80: -82dBm(MCS0), -57dBm(MCS9) 11ax: HE80: -82dBm(MCS0), -57dBm(MCS9), -52dBm(MCS11) 11ax: 160MHz: -77dBm(MCS0), -50dBm(MCS11)

1.3.3 Ports

Table 1-6 Ports

Item	Description
Bluetooth	Bluetooth 5.1
Fixed Service Port	One 10/100/1000 Base-T Ethernet port (IEEE 802.3af-compliant PoE) One 2.5G SFP port (compatible with 1G SFP port)
Fixed Management Port	One RJ45 Console port
LED	One system status LED
Button	One reset button

1.3.4 Power Supply

Table 1-7 Power Supply

Item	Description
Power Supply	DC power adapter: 48 V/0.6 A (Optional. Please refer to Power Supply for more details.) PoE: IEEE 802.3af-compliant
Max. Power Consumption	12.95 W

 **Caution**

The power adapter is optional. If you need to use a DC power adapter for power supply, please purchase an adapter that meets the corresponding safety requirements.

1.3.5 Environment and Reliability

Table 1-8 Environment and Reliability

Item	Description
Temperature	Operating: -10°C to 50°C (14°F to 122°F) Storage: -40°C to 70°C (-40°F to 158°F) At a height between 3000 m (9842.52 ft.) to 5000 m (16404.20 ft.) above the sea level, every time the altitude increases by 220 m (721.78 ft.), the maximum temperature decreases by 1°C (1.8°F).
Humidity	Operating: 0% to 95% (RH), non-condensing Storage: 0% to 95% (RH), non-condensing
Safety Certifications	GB 4943.1-2011, IEC 62368-1
EMC Certifications	EN 300386, GB/T 19286-2015, GB/T 17618-2015

1.4 Indicator and Button Description

 Note

In the description of the indicator status, unless otherwise specified, the indicator status description applies to both Fit AP and Fat AP.

Table 1-9 System indicator status description

Indicator Color	Blinking Frequency	Description
Off	None	The AP is not powered on, or has been powered on but the indicator is turned off by software.
Steady green	None	The AP is performing software system initialization.
Steady red	None	The system is running normally, but the uplink service port of the AP is Link Down.
Slow blink in red	On for 3s Off for 1s	In Fit AP mode, the establishment of a CAPWAP tunnel between the AP and the AC times out.
Fast blink in blue	On for 0.2s Off for 0.2s	In Fit AP or MACC AP mode, the AP is updating software system.

Indicator Color	Blinking Frequency	Description
Steady blue	None	The software system is running normally, and the AP is working normally but no wireless users are online.
Blinking blue	On for 1s Off for 1s	The software system is running normally. The AP is working normally and wireless users are online.
Fast blink in red	On for 0.2s Off for 0.2s	In Fit AP mode, the AP enables the indicator positioning function to find a specific AP.

Table 1-10 Reset key description

Button Type	Action	Result
Reset key	Press and hold for less than 2s	The device restarts.
	Press and hold for more than 3s	Restore the factory settings.

1.5 SFP Modules

The 2.5G SFP port of the AP supports both copper and fiber links. The negotiation speed may vary with the SFP module type and the speeds on both sides of the link.

Table 1-9 Negotiation Speed When Connected with SFP Port on Peer Device

AP SFP Port Speed	SFP Fiber Module Speed	Negotiation Speed		
		1 Gbps	1 Gbps/10 Gbps/Auto	1 Gbps/2.5 Gbps/10 Gbps/Auto
1 Gbps	3 Gbps	1 Gbps	1 Gbps	1 Gbps
1 Gbps	1 Gbps	1 Gbps	1 Gbps	1 Gbps
2.5 Gbps	3 Gbps	Not supported	Not supported	2.5 Gbps
2.5 Gbps	1 Gbps	Not supported	Not supported	2.5 Gbps

Table 1-10 Negotiation Speed When Connected with Copper Port on Peer Device

AP SFP Port Speed	SFP Copper Module Speed	Negotiation Speed		
		1 Gbps	1 Gbps/10 Gbps/Auto	1 Gbps/2.5 Gbps/10 Gbps/10

				Gbps/Auto
1 Gbps	2.5 Gbps	Not supported	Not supported	Not supported
1 Gbps	1 Gbps	1 Gbps	1 Gbps	1 Gbps
2.5 Gbps	2.5 Gbps	Not supported	Not supported	2.5 Gbps
2.5 Gbps	1 Gbps	Not supported	Not supported	Not supported

 **Caution**

- The 2.5G SFP port of the AP does not support speed negotiation. When you use the transceiver module, the speed of the AP, the module, and the port of peer device must be the same.
 - The SFP port and copper port can be multiplexed as a combo port. If two ports are connected with cables at the same time, AP will preferentially select the SFP port for data transmission (the copper port is automatically disabled). When the cable of SFP port is unplugged, the copper port is automatically enabled.
-

2 Preparing for Installation

2.1 Safety Precautions

Note

- To avoid personal injury and device damage, carefully read the safety precautions before you install the device.
 - The following safety precautions may not cover all possible dangers.
-

2.1.1 General Safety Precautions

- Do not expose the AP to high temperature, dusts, or harmful gases.
- Do not install the AP in an inflammable or explosive environment.
- Keep the AP away from EMI sources such as large radar stations, radio stations, and substations.
- Do not subject the AP to unstable voltage, vibration, and noises.
- The installation site should be free from water flooding, seepage, dripping, or condensation. The installation site should be selected according to network planning and communications equipment features, and considerations such as climate, hydrology, geology, earthquake, electrical power, and transportation.
- Keep the AP at least 500 meters away from the ocean and do not face it towards the sea breeze.
- Do not place the device in walking areas.
- During the installation and maintenance, do not wear loose clothes, ornaments, or any other things that may be hooked by the chassis.
- Keep tools and components away from walking areas.

2.1.2 Handling Safety

- Prevent the device from being frequently handled.
- Cut off all the power supplies and unplug all power cords before moving or handling the device.

2.1.3 Electric Safety

Warning

- Improper or incorrect electric operations may cause a fire, electric shock, and other accidents, and lead to severe and fatal personal injury and device damage.
 - Direct or indirect contact with high voltage or mains power supply via wet objects may cause fatal dangers.
-

- Observe local regulations and specifications during electric operations. Only personnel with relevant qualifications can perform such operations.
- Check whether there are potential risks in the work area. For example, check whether the power supply is grounded, whether the grounding is reliable, and whether the ground is wet.

- Learn about the position of the indoor emergency power switch before installation. Cut off the power switch in case of accidents.
- Check the device carefully before shutting down the power supply.
- Do not place the device in a damp/wet location. Do not let any liquid enter the chassis.
- Keep the device far away from grounding or lightning protection devices for power equipment.
- Keep the device away from radio stations, radar stations, high-frequency high-current devices, and microwave ovens.

2.1.4 Storage Safety

To ensure the normal operating of the device, see the storage temperature/humidity requirements in the specifications for the storage environment of the device.

 **Caution**

If the storage time exceeds 18 months, the device needs to be powered on and run for 24 hours without interruption for device activation.

2.2 Installation Environment Requirements

Install the device indoors to ensure its normal operation and prolonged service life.

The installation site must meet the following requirements.

2.2.1 Bearing Requirements

Evaluate the weight of the device and its accessories (for example, the bracket and power supply modules), and ensure that the ground of the installation site meets the requirements.

2.2.2 Ventilation Requirements

Reserve sufficient space in front of the air vents to ensure normal heat dissipation. After various cables are connected, bundle the cables or place them in the cable management bracket to avoid blocking air inlets.

2.2.3 Space Requirement

Maintain a minimum clearance of 0.4 cm (15.75 in.) around the device to ensure proper cooling and ventilation.

2.2.4 Temperature/Humidity Requirements

To ensure the normal operation and prolonged service life of the device, maintain an appropriate temperature and humidity in the equipment room.

The equipment room with too high or too low temperature and humidity for a long period may damage the device.

- In an environment with high humidity, the insulating material may have poor insulation or even leak electricity.
- In an environment with low humidity, the insulating strip may dry and shrink, loosening screws.
- In a dry environment, static electricity is prone to occur and damage the internal circuits of the device.
- Too high temperatures can accelerate the aging of insulation materials, greatly reducing the reliability of the device and severely affecting its service life.

Note

The ambient temperature and humidity of the device are measured at the point that is 1.5 m (59.06 in.) above the floor and 0.4 m (15.75 in.) before the device when there is no protective plate in front or at the back of the device.

2.2.5 Cleanliness Requirements

Dust poses a major threat to the device. The indoor dust takes on a positive or negative static electric charge when falling on the device, causing poor contact of the metallic joint. Such electrostatic adhesion may occur more easily when the relative humidity is low, not only affecting the service life of the device, but also causing communication faults. Table 2-1 describes the requirements for the dust content and granularity in the equipment room.

Table 2-1 Requirements for Dust

Dust	Unit	Content
Dust particles (diameter $\leq 0.5 \mu\text{m}$)	Particles/m ³	$\leq 1.4 \times 10^7$
Dust particles ($0.5 \mu\text{m} \leq \text{diameter} \leq 1 \mu\text{m}$)	Particles/m ³	$\leq 7 \times 10^5$
Dust particles ($1 \mu\text{m} \leq \text{diameter} \leq 3 \mu\text{m}$)	Particles/m ³	$\leq 2.4 \times 10^5$
Dust particles ($3 \mu\text{m} \leq \text{diameter} \leq 1 \mu\text{m}$)	Particles/m ³	$\leq 1.3 \times 10^5$

Apart from dust, the salt, acid, and sulfide in the air in the equipment room must meet strict requirements. These harmful substances will accelerate metal corrosion and component aging. Therefore, the equipment room should be properly protected against the intrusion of harmful gases, such as sulfur dioxide, hydrogen sulfide, nitrogen dioxide, and chlorine gas. Table 2-2 lists limit values for harmful gases.

Table 2-2 Requirements for Gases

Gas	Average (mg/m ³)	Maximum (mg/m ³)
Sulfur dioxide (SO ₂)	0.2	1.5
Hydrogen sulfide (HS)	0.006	0.03
Nitrogen dioxide (NO ₂)	0.04	0.15
Ammonia gas (NH ₃)	0.05	0.15
Chlorine gas (Cl ₂)	0.01	0.3

Note

Average refers to the average value of harmful gases measured in one week. **Maximum** refers to the upper limit of harmful gases measured in one week, and the maximum value lasts up to 30 minutes every day.

2.2.6 Anti-interference Requirements

- Take interference prevention measures for the power supply system.
- Keep the device away from the grounding equipment or lightning and grounding equipment of the power device as much as possible.
- Keep the device far away from high-frequency current devices such as high-power radio transmitting station and radar launcher.
- Take electromagnetic shielding measures when necessary.

2.2.7 Lightning Protection Requirements

The device can guard against lightning strikes. As an electric device, it may still be damaged by strong lightning strikes. Take the following lightning protection measures:

- Ensure that the neutral point of the AC power socket is in good contact with the ground.
- You are advised to install a power lightning arrester in front of the power input end to enhance the lightning prevention for the power supply.

2.2.8 Installation Site Requirements

Regardless of whether the device is installed on the wall or ceiling, the following conditions must be met:

- Maintain a minimum clearance of 0.4 cm (15.75 in.) around the device to ensure proper cooling and ventilation.
- The installation site allows for proper cooling and ventilation. You are advised to install an air conditioner if you want to install the device in a hot area.
- The installation side is sturdy enough to support the weight of the device and its accessories.

2.3 Tools

Table 2-3 Tools

Common Tools	Phillips screwdrivers, wires, Ethernet cable, fastening bolts, diagonal pliers, and binding straps
Special Tools	Antistatic gloves, wire stripper, crimping pliers, crystal connector crimping pliers, and wire cutter
Meter	Multimeter, and bit error rate tester (BERT)
Relevant Devices	PC, display, and keyboard

Note

The device is delivered without a tool kit. The tool kit and cables are customer-supplied.


3 Installing the Access Point

The RG-AP820-L(V3) AP must be fixed and installed indoors.

⚠ Caution

Before installing the device, make sure you have carefully read the requirements described in Chapter 2.

3.1 Installation Flowchart




3.2 Before You Begin

Before you install the device, verify that all the parts in the package contents are there and make sure that:

- The installation position provides sufficient space for heat dissipation.
- The installation position meets the temperature and humidity requirements of the device.
- The power supply and required current are available in the installation position.
- The Ethernet cable have been deployed in the installation position.
- The selected power supply modules meet the system power requirements.

- The position of the indoor emergency power switch is learned before installation. The power switch is cut off in case of accidents.
- For ceiling-mounted or wall-mounted AP, the mounting bracket size, mounting hole pattern and diameter should meet the requirements in **Table 1-4**.

Figure 3-1 Mounting Bracket



3.3 Precautions

To avoid damage to the AP, observe the following safety precautions:

- Do not power on the device during installation.
- Install the device in a well-ventilated location.
- Do not subject the device to high temperatures.
- Keep away from high voltage cables.
- Install the device indoors.
- Do not expose the device in a thunderstorm or strong electric field.
- Keep the device clean and dust-free.
- Disconnect the device before cleaning it.

- Do not wipe the device with a damp cloth.
- Do not wash the device with liquid.
- Do not open the enclosure when the device is working.
- Fasten the device tightly.

3.4 Installing the Access Point


i Note

- You are advised to install the device where you can get the optimal coverage.
- In the indoor area, the signal coverage of the ceiling-mounted device is larger than that of the wall-mounted device. Please choose the ceiling-mounting method first.

3.4.1 Ceiling Mounting


- (1) Drill four 6.5 mm (0.26 in.) diameter holes in the ceiling, 53 mm (2.09 in.) apart. Tap wall anchors into the holes, and drive screws through the mounting bracket into the anchors to secure the bracket.

Figure 3-2 Attaching the Mounting Bracket to the Ceiling



- (2) Align the square feet on the rear of the AP with the mounting holes on the bracket.

Figure 3-3 Aligning the Square Feet with the Mounting Holes




⚠ Caution

Install the Ethernet cables before mounting the AP on the bracket.

- (3) Slide the AP onto the bracket in the opposite direction of the arrow on the mounting bracket until it clicks into place.

Figure 3-4 Mounting the AP on the Bracket




⚠ Caution

- The AP can be installed in any of four directions on the mounting bracket depending on how you route the Ethernet cable.
 - The square feet should fit easily into the mounting slots. Do not forcibly push the AP into the slots.
 - After installation, verify that the AP is securely fastened.
-

3.4.2 Wall Mounting


- (1) Drill four 6.5 mm (0.26 in.) diameter holes in the wall and 53 mm (2.09 in.) apart, with the arrow on the mounting bracket facing up. Tap wall anchors into the holes, and drive screws through the mounting bracket into the anchors to secure the bracket.

Figure 3-5 Attaching the Mounting Bracket to the Wall



(2) Align the square feet on the rear of the AP with the mounting holes on the bracket.

Figure 3-6 Aligning the Square Feet with the Mounting Holes




⚠ Caution

Install the Ethernet cables before mounting the AP on the bracket.

(3) Slide the AP into the holes in the opposite direction of the arrows on the mounting bracket until it clicks into place.

Figure 3-7 Mounting the AP on the Bracket


**⚠ Caution**

- When mounting the AP on the wall, keep the Ruijie logo pointed upwards.
- The square feet should fit easily into the mounting slots. Do not forcibly push the AP into the slots.
- After installation, verify that the AP is securely fastened.

3.5 Securing the Access Point


- (1) Loosen the screw on the mounting bracket and engage the security screw.

Figure 3-8 Engaging the Security Screw



- (2) Align the square feet on the rear of the AP over the mounting holes on the bracket, slide the AP in the opposite direction of the arrows on the mounting bracket until it clicks into place.

Figure 3-9 Mounting the AP on the Bracket




⚠ Caution

Install the Ethernet cables before mounting the AP on the bracket.


3.6 Installing the SFP Module

- (1) Insert the SFP module.

Figure 3-10 Inserting the SFP Module




- (2) Connect the fiber.

Figure 3-11 Connecting the Fiber


3.7 Removing the Access Point

- (1) If the AP is installed on the ceiling, hold the AP in your hands and slide it sideways and away from the bracket in the LAN port direction.

Figure 3-12 Removing the Ceiling-mounted AP

- (2) If the AP is installed on the wall, hold the AP in your hands and push it upward and away from the bracket in the LAN port direction.

Figure 3-13 Removing the Wall-mounted AP



3.8 Connecting Cables

Connect UTP/STP to the LAN/PoE port on the AP. See Appendix A for supported wiring of twisted pairs.

Caution

By default, baud rate is set to 9600, data bit 8, parity none, stop bits 1 and flow control none on the Console port of the AP. The console port is used only when you want to configure the AP manually.

3.9 Bundling Cables

3.9.1 Precautions

- Make sure the cable bundles are neat and orderly.
- Bend twisted pairs naturally or to a large radius close to the connector.
- Do not over tighten cable bundle as it may reduce the cable life and performance.

3.9.2 Bundling Steps

- Bundle the drop UTP/STP cables and route them to the LAN/PoE port.
- Attach the cables in the cable tray of the rack.
- Extend the cables under the AP and run in straight line.

3.10 Checking after Installation

3.10.1 Checking Cable Connection

- Make sure the UTP/STP cable matches the interface type.
- Make sure cables are properly bundled.

3.10.2 Checking Power Supply

- Make sure all power ports are properly connected and compliant with safety requirement.
- Make sure the AP is operational after power-on.

4 Verifying Operating Status

4.1 (Optional) Configuring the Environment

Use a power adapter or PoE to power the AP.

Setting up the Environment

- Verify that the AP is properly connected to the power source.
- Connect the AP to an AC through a twisted pair cable.
- When the AP is connected to a PC, verify that the PC and PoE switch are properly grounded.

4.2 Powering up the AP

4.2.1 Checking Environment before Power-on

- Verify that the power supply is properly connected.
- Verify that the input voltage matches the specification of the AP.

4.2.2 Checking Environment after Power-on

After power-on, you are advised to check the following to ensure normal operation of the AP.

- Check if any message is printed on the Web-based configuration interface of the device.
- Check if the LED works normally.

5 Monitoring and Maintenance

5.1 Monitoring

5.1.1 LED

You can observe the LED to monitor the AP in operation.

5.1.2 CLI Commands

You can run related commands on the command line interface (CLI) of the device to remotely monitor the configurations and status of the AP.

Note

- You can log in to the AP via Telnet and use monitoring related commands to maintain the AP.
-

5.2 Remote Maintenance


- If the AP operates as a Fat AP, you can log in to the AP remotely for maintenance.
- If the AP operates as a Fit AP, you can use AC to centrally manage and maintain the AP.

5.3 Hardware Maintenance

If the hardware is faulty, please contact our Technical Assistance Center (TAC) for help.

6 Troubleshooting

6.1 Troubleshooting Flowchart



6.2 Typical Troubleshooting Cases

6.2.1 Ethernet Port Does Not Work After Being Connected to an Ethernet Cable

Check whether the device on the other end of the Ethernet is working normally, and then check whether the Ethernet cable matches the current working speed. In addition, check whether the cable is connected normally.

6.2.2 Indicator Is Off for a Long Time

- PoE power feeding: Check whether the other end of the PoE cable supports 802.11af or higher PoE standards, and then check whether the Ethernet cable is properly connected.
- Power adapter: Detect whether the adapter has received mains electricity, and then check whether the adapter works normally.

6.2.3 Indicator Remains Red for a Long Time

If the indicator stays red for a long time, it means that the Ethernet port cannot be connected. Check the connection on the Ethernet port.

6.2.4 Indicator Remains Green for a Long Time

The device needs to be initialized when it is powered on. During the initialization, the indicator is in steady green. When the initialization is finished, the indicator turns blue. Note: If the indicator is still green after 1 hour, the device initialization fails, and you can determine that the device is faulty.

6.2.5 Indicator Fast Blinks in Blue (Fit AP)

The software may be upgraded after the device is powered on. The indicator fast blinks in blue during software upgrade. When the software upgrade is finished, the indicator is steady blue. Note: The software upgrade time is uncertain, so do not turn off the device when the indicator is blinking. If the indicator still blinks after 10 minutes, the software upgrade fails, and you can determine that the device is faulty.

6.2.6 Indicator Is Not Steady Blue or Does Not Blink in Blue

After the system is started, if the indicator is not steady blue or does not blink in blue, the AP and the AC may not establish CAPWAP communication. Ensure that the AC has been started and the network configuration is correct.

6.2.7 Users Cannot Find Wireless Signals

- (1) Check whether the power feeding to the device is normal.
- (2) Check whether the link on Ethernet port is normal.
- (3) Check whether the AP is correctly configured.
- (4) Move the users' terminals to adjust the distance between terminals and AP.

7 Appendix

7.1 Connectors and Media


1000BASE-T/100BASE-TX/10BASE-T

The 1000BASE-T/100BASE-TX/10BASE-T is a 10/100/1000 Mbps auto-negotiation port that supports auto MDI/MDIX.

Compliant with IEEE 802.3ab, 1000BASE-T requires Category 5e 100-ohm UTP or STP (STP is recommended) with a maximum distance of 100 meters (328 feet).

1000BASE-T requires all four pairs of wires be connected for data transmission, as shown in **Figure 7-1**.

Figure 7-1 1000BASE-T Connection




10BASE-T uses Category 3, 4, 5 100-ohm UTP/STP and 1000BASE-T uses Category 5 100-ohm UTP/STP for connections. Both support a maximum length of 100 meters. **Figure 7-2** shows 100BASE-TX/10BASE-T pin assignments.

Figure 7-2 100BASE-TX/10BASE-T Pin Assignments

Pin	Socket	Plug
1	Input Receive Data+	Output Transmit Data+
2	Input Receive Data-	Output Transmit Data-
3	Output Transmit Data+	Input Receive Data+
6	Output Transmit Data-	Input Receive Data-
4,5,7,8	Not used	Not used

Figure 7-3 shows wiring of straight-through and crossover cables for 100BASE-TX/10BASE-T.

Figure 7-3 100BASE-TX/10BASE-T Connection



7.2 Mini-GBIC Modules

We provide appropriate SFP modules (Mini-GBIC) modules according to the port types. You can select the module to suit your specific needs. The following models and technical specifications of some SFP modules are listed for your reference.

Table 7-1 Models and Technical Specifications of the SFP Module

Wavelength (nm)	Media Type	Support DDM (Yes/No)	Intensity of Transmitted Light (dBm)		Intensity of Received Light (dBm)	
			min	max	min	max
1310Tx/1550Rx	Single-mode fiber	No	-9	-3	-	-18

Table 7-2 Cabling Specifications of the SFP Module

Port	Media Type	Core Size (μm)	Cabling Distance
LC	Single-mode fiber	9/125	0.3 km

 **Caution**


- For the fiber module with transmission distance exceeding 40 km and more, one on-line optical attenuator should be added on the link to avoid the overload of the optical receiver when short single-mode optical fibers are used.
 - Fiber modules generate laser. Do not stare at light source.
 - To keep fiber modules clean, please use dust caps when the modules are not connected with fibers.
-

7.3 Cabling Recommendations

During installation, route cable bundles upward or downward along the sides of the rack depending on the actual situation in the equipment room. All cable connectors should be placed at the bottom of the cabinet rather than be exposed outside of the cabinet. Power cords should be routed upward or downward beside the cabinet close to the location of the DC power distribution cabinet, AC power outlet, or lightning protection box.


- Required Minimum Cable Bend Radius
 - The minimum bend radius of a power, communication or flat cable should be 5 times the overall diameter of the cable. If the cable is constantly bent, plugged or unplugged, the bend radius should be 7 times the overall diameter.
 - The minimum bend radius of a coaxial cable should be 7 times the overall diameter of the cable. If the cable is constantly bent, plugged or unplugged, the bend radius should be 10 times the overall diameter.
 - The minimum bend radius of a high-speed cable, such as an SFP+ cable should be 5 times the overall diameter of the cable. If the cable is constantly bent, plugged or unplugged, the bend radius should be 10 times the overall diameter.
- Precautions for Cable Bundling
 - Before bundling cables, correctly mark labels and stick the labels to cables where appropriate.
 - Cables should be neatly and properly bundled, as shown in **Figure 7-4**.

Figure 7-4 Bundling Cables




- Route and bundle power, signal, ground cables separately. When the cables are close to each other, cross them. When power cords run parallel to signal cables, the distance between them must be greater than 30 mm.
- All cable trays and their accessories shall be smooth and free from sharp edges.
- Holes in metal, through which cables pass shall have smooth, well-rounded surfaces or be protected with insulating bushings.
- Use proper cable ties to bind cables together. Do not tie two or more cable ties to bind cables.
- Cut off excess cable tie cleanly with no sharp edges after bundling cables, as shown in Figure B-2.

Figure 7-5 Cutting off Excess Cable Tie




- o If cables are to be bent, bind them first but do not tie cable ties within the bend to avoid stress on the cables, which may otherwise cause the wires inside to break, as shown in **Figure 7-6**.

Figure 7-6 Do Not Tie Cable Ties within the Bend



- o Wrap up unnecessary or excess cables and bind them to the appropriate rack position, where device operation is not affected and no damages occur to the device and cables during debugging.
- o Do not bind power cords to the rails for moving parts.
- o Leave a certain length of the cable connecting moving parts, such as the ground wire of the cabinet door, to avoid stress on the cable; when moving parts are in place, ensure the excess cable length shall not contact heat sources, sharp corners or edges. If heat sources are unavoidable, use high-temperature cables instead.
- o When using screws to fasten cable lugs, the bolts or nuts shall be tightened and prevented from loosening, as shown in **Figure 7-7**.

Figure 7-7 Fastening Cable Lugs



Note

1. Flat washer	3. Spring washer
2. Nut	4. Flat washer

- o When using a stiff cable, fix it near the cable lug to avoid stress on the lug and cable.
- o Do not use self-tapping screws to fasten terminals.
- o Bundle cables of the same type and running in the same direction into groups. Keep cables clean and straight.
- o Cables shall be tied according to the following table.

Diameter of Cable Bundle (mm)	Space between Bundles (mm)
10	80 to 150
10 to 30	150 to 200
30	200 to 300

- o Do not tie knots for cables or cable bundles.
- o The metal parts of the cold-pressed terminal blocks, such as air circuit breakers, shall not be exposed outside of the blocks.

7.4 Power Supply

- DC power adapter:

Input voltage: 48 V

Rated current: 0.6 A

- Technical Specifications of the DC Power Connector

Inner Diameter	Outer Diameter	Depth	Polarity
2.1 mm	5.5 mm	10 mm	Inner positive, outer negative

Figure 7-8 Power adapter dimensions

