Since 1968



## **User Manual**

Door Camera DRC-4CPN3

## www.commax.com

COMMAX


## COMMAX Co.,Ltd.

- Thank you for purchasing COMMAX products.
- Please carefully read this User's Guide (in particular, precautions for safety) before using a product and follow instructions to use a product exactly.
- The company is not responsible for any safety accidents caused by abnormal operation of the product.




1. The names of Each Part


- 2. Wiring & Installation
- 3. Package
- 4. Specification









- Align holes on the wall where the unit is to be installed with mounting brackets hole and secure.
  - FIG-1 : Install the camera at a 30angle to the left (install the bracket in reverse to angle 30to the right)
  - FIG-2: Install the camera at a perpendicular angle to the front
- 2. Wire the household monitor cables as shown below with matched polarity as picture below[FIG-3]
  - (#1:RED/VOICE, #2:BLUE/GND,
- #3:YELLOW/DC12V, #4:BLACK/VIDEO)
- 3. Wire the door release cable as shown in the diagram.[FIG-3]
- 4. Tighten using bolts and a wrench, then cover using the AL. screw covers.











specification Mode	DRC-4CPN3
İmage Sensor	CMOS 1/3"
SensorResolution	0.52 megapixel
Powersource	12V (supplied from the Monitor)
Wiring(household)	Polar 4 wires
Call mode	Duplex
Camera angle	Horizontal angle 48.6° Vertical angle 37.5°
Format	NTSC or PAL STANDARD
Horizontal / vertical Frequency	15.734 kHz /60 Hz or 15.625 kHz /50
Lamp	Built-in white LED (automatically turns on in night)
Lowillumination	0.1 LUX (Up to 300mm in front of the camera)
Workable temperature	-10℃ (tested up to -40℃) +50℃
Dimension(mm)	59(W) x 164(H) x 42.1(D)
Weight(g)	415g (B/K included)
Warranty Period	1 year
Environment Condition	Storage Temperature -40 °C to 50 °C
• •	Storage Humidity Less than 90 %
Product Life-Cycle	10 years

## COMMAX Co.,Ltd.

513-11, Sangdaewon-dong, Jungwon-gu, Seongnam-si, Gyeonggi-do, Korea Int'l Business Dept. : Tel.; +82-31-7393-540~550 Fax.; +82-31-745-2133 Web site : www.commax.com

соммах

Printed In Korea / 2016.04.105